

### SERVER


SERVE BETTER™

SlimLine™

### **DRY FOOD DISPENSER**

MODEL: DFD

CAPACITY: 1.4 Liter 2 Liter



### Thank You

...for purchasing our SlimLine<sup>TM</sup> Dry Food Dispenser. This flavor station lets you dispense precise portions of candies, toppings and mix-in ingredients. Additional dispensers neatly mount side-by-side: (4) flavors every 13 inches.

ACCURATE, ADJUSTABLE PORTIONS IN LESS SPACE

# **QUICK START**

- YOU WILL NEED:
- Screwarive
- (4) screws &(4) anchor bolts (if needed)





# PRACTICE SAFETY. WASH ALL PARTS PROPERLY BEFORE USE. See page 5.



#### **INSTALL WALL BRACKET**

Select wall location or sturdy vertical surface for mounting.

Determine proper mounting hardware you will need to supply.

Secure bracket to wall stud(s), anchor bolts in wall, or sturdy vertical surface.






#### PLACE PORTION TRAYS

Color-coded trays indicate portion dispensed (by volume).

Slide all four trays of desired serving size into cylinder.

COLOF
White
Blue
Green
Pink




#### DID YOU KNOW?

The cylinder may be used without any portion trays. This yields portions each 2 fl oz.



#### ATTACH FRICTION PAD


Insert four triangular tabs on friction pad into matching slots in cylinder.





#### **INSTALL CYLINDER**


Slide cylinder, friction pad first, into the opening of dispenser body.





Slide handle over both sides of body and cylinder.


Snap handle centers into holes on each side.





6 INSTALL PIVOT PIN

Slide pivot pin into center hole on left side of handle.






unlock position.



Push pin in.
Rotate to the locked position.



- 8 FILL UNIT WITH INGREDIENT YOU WANT TO DISPENSE
- 9 PUT THE LID ON TOP OF THE UNIT




SWING HANDLE UPWARD to load the trav.

### **SWING HANDLE DOWNWARD**

to dispense the portion.


**TIP:** For cylinder to advance and serve a portion, the handle must travel its full range of motion up and down. Handle tabs must strike bottom.






# **DISASSEMBLY**

- REMOVE LID
- 2 EMPTY INGREDIENTS FROM UNIT
- 3 REMOVE ADAPTER CUP



REMOVE PIVOT PIN


Rotate pin to the unlock position and take it out.



REMOVE HANDLE


Use the pull-tab on right side to assist.

Lift handle upward to the position just before it would click. This makes the handle easier to remove.




REMOVE CYLINDER

Slide the cylinder out of the unit.



- REMOVE FRICTION PAD
- 8 REMOVE PORTION TRAYS



**NEXT: CLEAN** 

# SAFETY



According to food and safety regulations, most foods must be stored and/or served at certain temperatures or they could become hazardous. Check with local food and safety regulators for specific guidelines.

Be aware of the product you are serving and the temperature the product is required to maintain. Server Products, Inc. cannot be responsible for the serving of potentially hazardous product.



Clean, rinse, sanitize, and dry parts daily or regularly to comply with local sanitization requirements.

#### CAUTION

Keep fingers clear of all moving parts to prevent operator injury when dispensing product, during cleaning, assembly and disassembly.



NSF International listed.

ADA compliant

### **CLEANING**



After disassembling, clean all washable parts with soap and hot water.



fully with clear water.




all parts according to local sanitization requirements. All parts in contact with food must be sanitized.

4 AIR DRY all parts fully.



- External surfaces may be wiped clean with a clean damp cloth.
- Glass and surface cleaners approved for use in food contact areas may be used.
- Do not use abrasive, caustic or ammonia based cleansers.
- Do not use metal scrapers or cleaning pads that could scratch surfaces.

# **TROUBLESHOOTING**



# SERVER PRODUCTS LIMITED WARRANTY





All Server Products equipment is backed by a two-year limited warranty against defects in materials and workmanship.

For complete warranty information go to:

### www.Server-Products.com


### GENERAL SERVICE, REPAIR OR RETURNS

Before sending any item to Server Products for service, repair, or return, contact Server Products customer service to request a **Return Authorization Number**. Merchandise must be sent to Server Products with this number. Service is extremely prompt. Typically, units are repaired and ship out within 48 hours of receipt.

Merchandise being returned for credit must be in new and unused condition and not more than 90 days old and will be subject to a 20% (percent) restocking charge.

# SLIMLINE™ DRY FOOD DISPENSER

### MODEL: DFD



### **NEED HELP?**

#### Server Products Inc.

3601 Pleasant Hill Road Richfield, WI 53076 USA



262.628.5600 | 800.558.8722

SPSALES@SERVER-PRODUCTS.COM

Please be prepared with your **Series Number** and **Description** located on the lid of the unit.

Individual Part Numbers listed above.